


USB Server – Driver Installation

The new Bridgemate II USB server is fully USB 2.0 (and 1.1) compliant. Usually, once the driver has been installed, the USB server may be connected to any USB port. However, on some computers it will be necessary to always use the same USB port or install the driver on each USB port.

Before connecting the USB server to the PC:

1. Normally, the Bridgemate Control Software (BCS) “full install” program will also install the USB Server driver on your PC.
 - If you note that the driver has been installed, skip to item 2 below.
 - If there was no indication the driver was installed, Run the “BMinfSetup.msi” program. This file is on the Bridgemate Flash Drive in the Drivers/USB Server folder or downloaded from www.bridgemate.us/resources/drivers/BMinfSetup.msi
2. After the driver has been installed (by the BCS installation or running the BMinfSetup.msi program), connect the USB server to the computer. Depending on the Windows® operating system, the driver will be installed automatically or there will be a prompt (probably the "New Hardware Wizard") that new hardware has been found and Windows® needs to install a driver. Do not let Windows search the Internet; on the next screen - let Windows automatically search for the driver on your computer. The driver should be found and installed

If the driver is not installed automatically:

- Connect the USB Server to your PC and locate Windows' Device Manager.
 - Windows XP: Start → Control Panel → System → Hardware → Device Manager
-or- → Performance and Maintenance → System → Hardware → Device Manager.
 - Windows 7 / Vista: Start → Computer → System Properties → Device Manager
 - Windows 8: Special procedures are required. See “Windows 8 – Bridgemate USB Server – Driver Software” starting on the next page.
- Look for “Bridgemate Server” with a yellow alert flag.  Right click on this entry and left click on Update Driver.
 - Windows XP: It should display the “New Hardware Wizard” (see above);
 - Windows 7 / Vista: Click on “Search automatically...”
- The driver should be found and installed. If not, follow the manual procedure described below.

Install driver manually:

In Device Manager right click on Bridgemate server and left click on Update driver.

- Windows XP: It should display the “New Hardware Wizard”
 - Click “No, not this time” – Do not go to the Internet to search for the driver – click “Next”
 - Click “Install from a list or specific location (Advanced) – click “Next”
 - Uncheck “Search...” and check “Include this location in the search”
 - Click “Browse”
 - Go to “My computer” → Bridgemate flash drive → click OK
 - This returns you to the previous screen: Click “Next”
 - The driver will be installed.
- Windows 7 / Vista:
 - Click on “Browse my computer for driver software”
 - Below Search for Driver software in this location click on “Browse”
 - In the Browse for Folder window, go to “Computer” → Bridgemate flash drive → click OK
 - This returns you to the previous screen: Click “Next”
 - The driver will be installed.

After the driver is installed, please start the Bridgemate Control Software from "All Programs" → "Bridgemate Pro" → Bridgemate Control Software. You may need to disconnect and reconnect the server before the Bridgemate program will show that the server is "Connected."

Windows 8 – Bridgemate USB Server – Driver Software

After installing the USB Server driver software as part of the Bridgemate Control Software (BCS) installation, you may encounter this error notice when the server is connected.

Close this notice and follow the instructions below to bypass this Windows-8 difficulty.




First, press and while holding the **win** key press the letter **I** to launch the charm bar – or move the cursor to upper right of the screen to show the charm bar.

Click **Change PC Settings** at the bottom of the charm bar.


Then, go to **General**, and scroll (on the right side panel) to the bottom of the page.

Click **Restart Now** button under **Advanced Startup** section. Remember to save all your work first before clicking it.


The **computer** reboots to a startup “Choose an option” menu. Click **Troubleshoot**.




Click **Advanced Options** on the next “Troubleshoot”) screen.



Choose **Startup Settings** on the next “Advanced Options” screen.




On the next “Startup Settings” screen, click on the **Restart** button.



The computer reboots and displays a “Startup Settings” menu. (See next page)

On this “Startup Settings” screen, one of the items is **Disable driver signature enforcement**.

Press number **7** to continue booting to **Windows 8** with digital sign enforcement **disabled**.




To install the USB Server’s driver software (now that “Driver Signature Enforcement” has been disabled, go to the lower-left corner of the screen and right click. Select **Device Manager** on the displayed list.

In **Device Manager** there should be an entry such as “Bridgemate Server” followed by a yellow symbol. This symbol confirms the USB Server driver has not been installed.

Right click on this entry. Click on **Update Driver software**. Select the “**Browse**” option.



Then this **Windows Security** warning window should appear.

Click on **Install this driver software anyway**.




Note: When the computer is restarted, the **digital** sign enforcement will be re-enabled..

If Bridgemate Control Software still shows the Server as "Not connected," follow these additional steps.




1. Right click screen lower-left corner & go to Device Manager

2. Right click



3. Left Click



4. Left click



5. Left click



6. Windows 8 confirms that the driver is installed.



Device Manager shows server now recognized as a COM port.